




Drum Set Rental Easy Start Guide




Start with setting the throne height so that the upper and lower portions of your legs form a right angle, the thighs parallel with the floor.



Now add the snare drum. Set the height so that the top of the drum is roughly at the same height of the top of your legs. This can be fine-tuned once the whole kit is assembled. The snare has a "throw-off" lever which stretches the snare wires across the bottom skin, creating the distinctive snare "rattle" sound.



Now add the bass drum. Extend the spurs so that the drum sits evenly on the floor, and attach the pedal to the hoop.



The hi hat cymbals are mounted on the hi hat stand. The top cymbal is sandwiched between the two pieces of the "clutch." The stand also has a foot pedal used to create different effects and sounds.



The toms sit on a mounting system that attaches to the bass drum.



The floor tom has three legs that are used to set its height and angle.



The ride and crash cymbals come next. The ride goes somewhere between the largest mounted tom and floor tom. The crash should be positioned somewhere above the smallest tom. It's important to make sure there are felt washers above and below the cymbal.



Make sure that the heights and angles of each component are set up in a way that is most comfortable for you. Try to avoid having to reach too far for any part of the kit. Most of all, ENJOY! Feel free to get in touch with our drum department if you have any questions or need any further help.